
## **MODEL-L2**

# **REMOTE MOUNT BLOCK AND BLEED TWO VALVE MANIFOLD** 413 bar (6000 psi)







#### **APPLICATION**

#### **Using The 2-Valve Manifold**

In normal operation the "isolate" valve is open while the "vent" valve is closed. To remove the instrument, first close the "isolate" valve, then open the "vent" valve to relieve pressure upstream of the "isolate" valve.

### **Calibration Options**

By connecting a calibration gauge to the vent port, it is possible to

check the calibration of the instrument without removing it from the installation.

Also available in a range of other materials and options (See HOW TO ORDER Data Sheet)

WEIGHT = 1.0 kg



